

# **Technical Data Sheet**


Pressure / Temperature / Humidity / Air Velocity / Airflow / Sound level

# **KIRAY 100** Infrared thermometer



### Distance from the target

Distance	254	260	508	mm
Diameter	12.7	13	25.4	mm
[				
F		D:S=20:1 13 mm at 260 mm		



Make sure that the target is larger than the size of the laser sighting.


Infrared thermometer **KIRAY 100** with dual laser sighting is a key tool to diagnose, inspect and check any temperature, with the advantage of using "no-contact" technology. You can safely measure surface temperatures of hot objects, dangerous or difficult to access. Perfect tool to take temperature in a house, a garage, a workshop, an office, a car, a kitchen etc...

New CE

## Technical features

	0.44
Spectral response	
Optical	D.S : 20:1 (13 mm at 260 mm)
Temperature range	From -50 to +800°C
Accuracy*	. From -50 à +20°C : ±2.5°C
	From +20 to +300°C : $\pm$ 2% of reading $\pm$ 2°C
	From +300°C to +800°C : ±2% of reading
Infrared repeatability	From -50 to +20°C : ±1.3°C
	From +20 to +800°C : ±0.5% or ±0.5°C
Display resolution	0.1°C
Response time	
	Adjustable from 0.10 to 1.0 (pre-set at 0.95)
Over range indication	Display indication : « »
	Wave length : from 630 nm to 670 nm
	Output < 1mW, Class 2 (II)
Positive or negative	
-	Automatic (no indication for a positive
•	temperature)
	(-) sign for a negative temperature
Display	4 digits with LCD backlighted display
	Automatic after 7 seconds of inactivity
	. Flashing signal on display and beep signal
	with adjustable thresholds
Power supply	
	105 h (inactive laser and backlight)
•	20 h (active laser and backlight)
	From 0 to $+10^{\circ}$ C for a short period
	From +11 to +50 °C for a long period
Storage temperature	
	From 10 to 90%HR in operating mode
Relative numbers	and > 80%RH in storage
Dimensions	
Weight	
**CIGIIL	Too g (moluded ballery)

\*Accuracy for an ambient temperature from 23 to 25  $^\circ C$  (with a relative humidity lower than 80% RH)



- 1 Technical unit °C/°F
- 2 Low battery indicator
- 3 Emissivity value = 0.95 (factory setting)
- 4 Max temperature indicator.
- 5 Temperature value
- 6 Current measurement indicator
- 7 HOLD indicator (fixed measurement)
- 8 Laser in operation indicator
- 9 Lock indicator (continuous measurement) 10 – High alarm symbol (fixed : activated alarm ;
- flashing + beep : alarm thresholds exceeded)
- 11 Low alarm symbol (fixed : activated alarm ; flashing + beep : alarm thresholds exceeded)

#### KIRAY 100 buttons



- Up button. It allows to increment emissivity and high/low alarm thresholds. This button also allows in measurement mode to activate or deactivate the laser.
- 2 Mode button. It allows to navigate through the modes (emissivity, lock, high alarm, low alarm).
- 3 Down button. It allows to decrement emissivity and high/low alarm thresholds. This button also allows in measurement mode to activate or deactivate the backlight.

### Infrared thermometer, how does it work ?

Infrared thermometers can measure the surface temperature of an object. Its optic lens catches the energy emitted and reflected by the object. This energy is collected and focused onto a detector. This information is displayed as temperature. The laser pointer is only used to aim at the target.





#### www.kimo.fr

afao

9001

EXPORT DEPARTMENT Tel : + 33. 1. 60. 06. 69. 25 - Fax : + 33. 1. 60. 06. 69. 29 e-mail : export@kimo.fr Distributed by :